

## Garmin - Chart compatibility table

X = Not Compatible L=Limited C = Compatible R = Recommended

Description	Memory Type	g3(*) S & R sizes	g3(*) L & XL sizes	g3 Vision S & R sizes	g3 Vision L & XL sizes
Colorado Series	microSD/SD	X	X	X	X
Dakota Series	microSD/SD	X	X	X	X
EchoMAP 50s / 50dv / 70s / 70dv	microSD/SD	C	C	R	R
EchoMAP 42 / 45 / 52 / 55 / 71 / 72 / 75 / 91 / 92 / 95	microSD/SD	C	C	R	R
EchoMAP CHIRP 42 / 45 / 52 / 55 / 72 / 75 / 92 / 95	microSD/SD	C	C	R	R
EchoMAP Plus 42 / 45 / 62 / 65 / 72 / 75 / 92 / 95	microSD/SD	C	C	R	R
EchoMAP Ultra 102 / 122	microSD/SD	C	C	R	R
eTrex 20x / 30x	microSD/SD	X	X	X	X
eTrex Touch	microSD/SD	X	X	X	X
GPSmap 1022 / 1222 (including XSV models)	microSD/SD	C	C	R	R
GPSmap 1222 Touch / 1222 Touch XSV	microSD/SD	C	C	R	R
GPSMAP® 276Cx	microSD/SD	R	R	X	X
GPSMAP 4008	microSD/SD	L	L	L	X
GPSMAP 4010	microSD/SD	L	L	L	X
GPSMAP 4012	microSD/SD	L	L	L	X
GPSMAP 420	microSD/SD	L	L	L	X
GPSMAP 420s DF xdcr	microSD/SD	L	L	L	X
GPSMAP 420s w / o xdcr	microSD/SD	L	L	L	X
GPSMAP 421 / 421S	microSD/SD	L	L	L	X
GPSMAP 451 UK	microSD/SD	L	L	L	X
GPSMAP 451s UK w / o xdcr	microSD/SD	L	L	L	X
GPSMAP 5008	microSD/SD	L	L	L	X
GPSMAP 5012	microSD/SD	L	L	L	X
GPSMAP 5015	microSD/SD	L	L	L	X
GPSMAP 520	microSD/SD	L	L	L	X
GPSMAP 520s DF xdcr	microSD/SD	L	L	L	X
GPSMAP 520s w / o xdcr	microSD/SD	L	L	L	X
GPSmap 521 / 721	microSD/SD	C	C	R	R
GPSMAP 525	microSD/SD	L	L	L	X
GPSMAP 525s DF xdcr	microSD/SD	L	L	L	X
GPSMAP 525s w / o xdcr	microSD/SD	L	L	L	X
GPSMAP 526 / 526S	microSD/SD	L	L	L	X
GPSMAP 551 UK	microSD/SD	L	L	L	X
GPSMAP 551s UK w / o xdcr	microSD/SD	L	L	L	X
GPSMAP 556 UK	microSD/SD	L	L	L	X
GPSMAP 556s UK w / o xdcr	microSD/SD	L	L	L	X
GPSmap 527 / 557 / 721 / 751 (including XS models)	microSD/SD	C	C	R	R

X = Not Compatible L=Limited C = Compatible R = Recommended

Description	Memory Type	g3(*) S & R sizes	g3(*) L & XL sizes	g3 Vision S & R sizes	g3 Vision L & XL sizes
GPSMAP 6008	microSD/SD	L	L	L	X
GPSMAP 6012	microSD/SD	L	L	L	X
GPSMAP 60CSx	microSD/SD	X	X	X	X
GPSMAP 60Cx	microSD/SD	X	X	X	X
GPSMAP 62	Built in	X	X	X	X
GPSMAP 620	microSD/SD	X	X	X	X
GPSMAP 62S	microSD/SD	X	X	X	X
GPSMAP 62ST	microSD/SD	X	X	X	X
GPSMAP 64 series	microSD/SD	X	X	X	X
GPSMAP 66 series	microSD/SD	X	X	X	X
GPSMAP 7012	microSD/SD	L	L	L	X
GPSMAP 7015	microSD/SD	L	L	L	X
GPSmap 720 / 720s	microSD/SD	L	L	L	X
GPSmap 722 / 922 (including XS models)	microSD/SD	C	C	R	R
GPSmap 74xx (including XSV models)	microSD/SD	C	C	R	R
GPSMAP 750 UK	microSD/SD	L	L	L	X
GPSMAP 750s UK w / o xdcr	microSD/SD	L	L	L	X
GPSMAP 76CSx	microSD/SD	X	X	X	X
GPSMAP 76CX	microSD/SD	X	X	X	X
GPSMAP 76Cx	microSD/SD	X	X	X	X
GPSMAP 78	microSD/SD	R	R	X	X
GPSMAP 78s	microSD/SD	R	R	X	X
GPSmap 80xx / 8520	microSD/SD	C	C	R	R
GPSmap 820 / 1020 (including XS models)	microSD/SD	C	C	R	R
GPSmap 84xx (including XSV models)	microSD/SD	C	C	R	R
GPSmap 87xx (black box)	microSD/SD	C	C	R	R
Montana 6x0	microSD/SD	X	X	X	X
Monterra	microSD/SD	X	X	X	X
nüvi 5XX series	microSD/SD	X	X	X	X
Wearable (map supported)	microSD/SD	X	X	X	X
Oregon Series	microSD/SD	X	X	X	X